


FUJI 4040



MODEL	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
4040	40"	40"	33"	10½"	10½"	15"	10¼"	2"	32"	29½"	16"	14"	23"	9"	1¾"	9"