


FUJI 6040



MODEL	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
4040	60"	40"	32"	20"	30"	2"	10½"	2"	32"	29½"	21½"	49"	30"	8"	1¾"	1½"